



Bubbling Rock

Installation Instructions

NOTES: Please check for any damage caused by the shipping company and take appropriate steps to file a claim, if needed.

*Please call **Digsafe** and check for any underground utilities before digging anywhere.

Materials needed

Trenching shovel, spade shovel, tape measure, hand tamp, teflon tape, one (1) 2-way Y shut-off hose connector, two (2) 3/4" male to slip PVC adapters, 3/4" schedule 40 PVC pipe, 3/4" schedule 40 PVC couplers, two (2) stainless steel washing machine hoses, PVC glue and primer.

Instructions

1. Remove items from pallet.
2. Determine where you want to place the bubbling rock.
3. Trench from your spigot to the bubbling rock using a trenching shovel.
4. Now you'll hook up the plumbing from the spigot to the bubbling rock. Attach a 2-Way Y Shut-Off Metal Hose Connector to your spigot.

*Note: Use teflon tape on all threaded connections.

5. Attach one of the stainless steel washing machine hoses to the 2-way shutoff.
6. Attach a 3/4" male to slip PVC adapter to the washing machine hose.
7. Connect your 3/4" PVC pipe, and run it down the trench until your within a couple feet of the bubbling rock.
8. Attach a 3/4" male to slip adapter to the end of the PVC pipe.
9. Attach the second washing machine hose to the 3/4" male to slip adapter.
10. Connect the other end of the washing machine hose to the underside of the bubbling rock.
11. Water flow out of the bubbling rock can be controlled by the shut-off attached to the spigot.
12. Enjoy your Bubbling Rock!