



Wind Chimes

Installation Instructions

NOTES: Please check for any damage caused by the shipping company and take appropriate steps to file a claim, if needed.

*Please call **Digsafe** and check for any underground utilities before digging anywhere.

Materials needed

Driver / drill, Post hole shovel, spade shovel, level, tape measure, hand tamp, and fourteen (14) 50lb bags of fast-setting premixed concrete (not included). Concrete amount required may vary depending on how deep you can get the holes. Concrete amounts can be easily calculated at <http://www.quikrete.com/Calculator/Main.asp>.

Instructions

1. Remove items from packaging. You should find one (1) wind chime assembly.
2. Hang the wind chime off a tree branch and let the wind do the rest!
3. All wood is treated with kid-friendly preservative, but as is the case with all wood facing the elements, it needs to be cared for, so check it periodically for rough spots, splinters, etc, and sand them out, and treat it with kid-friendly wood preservative (we have it available if you can't find it) once or twice a year to keep the wood from deteriorating.
4. Enjoy your Wind Chimes!



Image 1: Wind Chime