



Picnic Table Installation Instructions

NOTES: Please check for any damage caused by the shipping company and take appropriate steps to file a claim, if needed.

*Please call **Digsafe** and check for any underground utilities before digging anywhere.

Note: depending on the configuration of the shipping pallet, your picnic table may come in a kit or may come fully assembled. If it is in kit form, here are the assembly instructions.

Materials needed

Cordless driver, star drive bit.

- 1) Lay everything out so you can see what you have. Basically, there is the top, which is the largest piece, the seats, the four legs, the two seat supports that connect between the legs, and the two angle supports that go from the two-seat supports up under the table to the top, plus the hardware.
- 2) Find the four legs matching angle cuts at top and bottom, and find the two-seat supports. Attach them as shown in the picture.
- 3) Turn the table top upside down so that the bracing is facing up, turn the leg assembly upside down as well, squeeze the legs together until they line up with the holes in the table top cleat, and fasten together.
- 4) Find the two short angle braces that go from the seat support to the underside of the table, and fasten as shown.
- 5) Set table upright, and fasten both seats as shown.
- 6) All the wood is treated with kid-friendly preservative, but as is the case with all wood facing the elements, it needs to be cared for, so check it periodically for rough spots, splinters, etc, and sand them out, and treat it with kid-friendly wood preservative (we have it available if you can't find it) once or twice a year to keep the wood from deteriorating.
- 7) Now you're all set to have a picnic!

Picnic Table

Installation Instructions

